**BT-340**

RADIO AM/FM

# MANUAL DE INSTRUCCIONES

# CONTROLES




1. Control de volumen
2. Toma de auriculares
3. Antena telescópica
4. Frecuencia
5. Indicador de emisora
6. Altavoz
7. Encendido/Apagado; Selector FM/AM
8. Compartimiento de pilas
9. Ajuste la perilla

# USO DE LA RADIO

### Instalación de pilas

Abra la tapa de las pilas e inserte 2 x AAA / UM4 de acuerdo con el diagrama de polaridad impreso en el compartimiento de la batería.



**Encender/Apagar la radio**
Presione el botón [POWER OFF / AM / FM] hacia arriba para encender la unidad y seleccionar AM / FM. Pulse de nuevo hacia abajo hasta la posición más baja [POWER OFF] para apagarla.

**Banda FM**
Para escuchar emisiones de FM, extienda completamente la antena telescópica y pulse el botón [POWER OFF / AM / FM] a la posición FM, luego gire el control [TUNING] para sintonizar la emisora FM deseada.

**Banda AM**
Para escuchar AM, pulse el botón [POWER OFF / AM / FM] hacia la posición AM, extienda completamente la antena telescópica, a continuación, gire el selector [TUNING] para sintonizar la emisora AM deseada.

**Ajuste de volumen**
Gire la rueda [Volumen] en el panel superior para ajustar el volumen.

**Uso de auriculares/altavoz**
Auriculares: Reducir el nivel de volumen, a continuación insertar los auriculares en el conector de auriculares para escuchar la radio.



Altavoz: La unidad cambiará automáticamente el sonido al altavoz al desconectar los auriculares de la unidad.

Medidas de seguridad

- No exponga el aparato a la luz solar, cerca de fuentes de calor, ni lo deje en el lugar con polvo excesivo o donde pueda sufrir golpes.
- No exponga la radio a la lluvia y al medio ambiente húmedo.
- No utilice líquidos abrasivos para limpiar, límpielo con un paño suave humedecido con agua.
- Si el sonido es bajo o distorsionado, cambie todas las pilas por otras nuevas. No mezcle baterías nuevas y antiguas.
- Si la unidad no se utiliza durante un tiempo prolongado, retire las pilas para evitar fugas o corrosión.

*"Las especificaciones pueden cambiar sin previo aviso"*

IMPORTADO
I.R.P., S.L.
AVDA. SANTA CLARA DE CUBA 5
SEVILLA, SPAIN

**DECLARACIÓN DE CONFORMIDAD**

I.R.P., S.L. declara bajo su responsabilidad que el aparato indicado cumple los requisitos de las siguientes directivas:

**DIRECTIVAS EMC**

EN55013:2001+A1:2003+A2:2006

EN61000-3-2:2006+A1:2009+A2:2009

EN61000-3-3:2008

EN55020:2007

Descripción del aparato:

Modelo BRIGMTON **BT-340**

Radio con altavoz incorporado

Importador: I.R.P., S.L.

Dirección: Avda. Santa Clara de Cuba 5, 41007, Sevilla.

BRIGMTON

**BT-340**

AM/FM RADIO

# OPERATION MANUAL

# LOCATIOIN OF CONTROLS







1. Volume knob
2. Earphone jack
3. Telescopic antenna
4. Frequency dial scale
5. CHA. light
6. Speaker
7. Power on / off；FM/AM band switch
8. Battery compartment
9. Tuning knob

# USING THE RADIO

**Battery installation**

Open the battery cover and insert 2 x AAA / UM4 battery according to the polarity diagram imprinted on the battery compartment.



**Turn on / off the radio**

Push the [POWER OFF/ AM / FM] button upwards to turn on the unit and select either AM/FM band; downwards to the lowest position [POWER OFF] to turn off the radio.

**Listen to FM band**

When listening to FM broadcasting, fully extend the Telescopic antenna and push the [POWER OFF/AM/FM] switch to FM location, then rotate the [TUNING] knob for your desired FM station.

**Listen to AM band**

When listening to AM broadcasting, push the [POWER OFF/AM/FM] switch to AM location, then rotate the [TUNING] knob for your desired AM station.

As the internal Ferrite bar functions as the antenna of AM, you should rotate the unit for better reception.

**Adjust Volume**

Rotate the [Volume] knob on the top panel to adjust the volume.

**Listenning via Earphones / Speaker**

Earphones listening: Reduce the volume level then insert the earphones into the earphone jack for listening.



Speaker listening: The unit will switch for speaker sound automatically when you disconnect the earphones from the unit.

**PRECAUTIONS**

- Do not let the radio expose to sunlight, close to heat sources, or leave it in the place with excessive dust or mechanical shock.
- Do not expose the radio to rain and humid environment.
- Do not turn it on outside building while thundering and lightning.
- Do not use any abrasive powder to clean the cabinet, wipe it by a soft cloth moistened with mild soap and water.
- If the sound becomes low or distorted, replace all the batteries with new ones. Do not intermix old and new batteries together.
- If the unit is not used for a long time, remove all the batteries to prevent battery leakage or corrosion.

*"Features can change without notice"*
IMPORTED
I.R.P., S.L.
AVDA. SANTA CLARA DE CUBA 5
SEVILLA, SPAIN

**DECLARATION OF CONFORMITY**

I.R.P., SL declare under our responsibility that the equipment meets the requirements indicated in the following directives:

**EMC DIRECTIVES**
EN55013: 2001 + A1: 2003 + A2: 2006
EN61000-3-2: 2006 + A1: 2009 + A2: 2009
EN61000-3-3: 2008
EN55020: 2007

Description of apparatus:
BRIGMTON Model **BT-340**
Radio with built-in speaker
Importer: I.R.P., SL
Address: Avenida Santa Clara de Cuba 5, 41007, Sevilla.